


USER MANUAL

**TRACK SYSTEM
FOR ATV**

1099-01-1010 - VERSION D

CAMOPLAST
TATOU ATV **T4S**



2012



camoplast
HI-PERFORMANCE TRACKS

Camoplast Solideal Inc.
4162, Burrill - Local A
Shawinigan, (Québec) G9N 0C3 CANADA

E-mail : atvtracksystems@camoplastsolideal.com
Website : www.camoplastsolideal.com

IMPORTANT

Please read carefully each part of this document as well as model specific Installation Guidelines prior to assembling, installing and using the track system.

Original notice

Other languages translation available at www.camoplastsolideal.com

TABLE OF CONTENTS

INTRODUCTION	1
SAFETY	1
GENERAL INFORMATION	2
HINTS AND TIPS	2
USER NOTICE AND DISCLAIMER	3
USING THE ATV WITH TRACKS	5
INSTALLATION, REMOVAL AND RE-INSTALLATION	14
ADJUSTMENTS	18
INSTALLATION OF A RUBBER TRACK	30
BREAK-IN PERIOD	33
REPLACEMENT OF A WHEEL WITH EXTRACTOR	34
MAINTENANCE SCHEDULE	36
TORQUE TABLE	37
STORAGE	37
WEAR	38
WARRANTY	43
TROUBLESHOOTING	45
SERIAL NUMBER LOCATION	46
TECHNICAL SUPPORT	47
"CE" DECLARATION OF CONFORMITY	48
PARTS LIST	50

INTRODUCTION

Thank you for choosing the **Camoplast T4S** , a Camoplast Hi-Performance Tracks ATV Track System, (hereinafter referred to as the "System"). You have made the right choice. This system will provide you with all the traction, performance and durability you require for recreational or work purposes and allows for year-round operation. This track system for **quads** (hereinafter referred to as the "ATVs") provides exceptional floatation with very low ground pressure. Its strong lightweight steel frame (30 kg), its internal sprockets, adapted to the vehicle's capacity, and its track, specifically designed for ATVs, make it the best system on the market.

SAFETY

This guide uses the following symbols to emphasize particular information :

 **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in damage to vehicle components.

NOTE: Indicates supplementary information.

GENERAL INFORMATION

All figures, information or photos presented in this document are up to date at the time of publication. However, they may change without notice.

Read and follow indications of the ATV user manual and installation guidelines carefully. Their contents remains applicable after installing of the System.

This document should be read by every person who drives the ATV equipped with the System.

This document is an integral part of the System. Pass it along to any new System owner.

Consult legal authorities where you drive your ATV equipped with the System before usage to ensure that you respect all applicable laws and regulations.

ATV track systems are designed to reduce ground pressure and increase vehicle traction. However, during normal operating conditions, vehicle speed will be reduced, compared to a wheeled vehicle.

HINTS AND TIPS

Before leaving for an excursion, make sure you have the following within arms reach : 12 mm, 14mm, 16 mm, 15 mm, 17 mm, 19mm and 30 mm wrenches, one axe, one shovel, one tow cable, a lifting jack and one adjustable wrench.

Generally, the slower you go, the better the traction will be.

For riding or excursions in unknown, or remote terrain, make sure you have a cellular phone or satellite phone, a first aid kit and spare parts in your possession.

When driving off trails, always be cautious to the presence of hidden obstacles.

When driving in deep snow, do not intentionally spin the track (tracks keep on turning while the vehicle does not). This could cause the vehicle to get stuck.

USER NOTICE AND DISCLAIMER

The **Camoplast T4S** System was initially designed to be used in winter conditions and was then adapted to be used in fall and spring conditions.

This document holds important information regarding driving an ATV equipped with the **Camoplast T4S** System by Camoplast Hi-Performance Tracks. It is mandatory that every user takes the time to carefully read, understand and then consult this reference manual and user guide as well as the ATV owner's manual as needed. When purchasing either a new or used track System, the user must obtain all documentation related to the System, including manuals and guides related to the ATV on which the System is installed. If need be, contact the Camoplast Hi-Performance Tracks products dealer nearest to you to obtain any additional information. You may also consult the Camoplast Solideal Web site at www.camoplastsolideal.com and call our technical support by email at atvtracksystems@camoplastsolideal.com.

Camoplast Hi-Performance Tracks believes that there are certain risks related to the installation and use of the System. Our experience shows that the System is safe. However, the user must be aware of the risks related with driving an ATV with the particularities of this type of System. The ATV driver must, at all times, respect all applicable laws and regulations, the indications of the System manufacturer and the indications from the vehicle manufacturer fixed by law, namely when age restrictions exist and ATV base equipment is required (headlights, flashers and brake lights, rearview mirror, etc.). The user must always wear adequate safety equipment, such as a helmet, safety glasses (or visor), protective clothing, boots and gloves. It is understood that driving while impaired or intoxicated presents a danger for the ATV user and others and is against the law.

The System consists of many moving parts, including transmission wheels. If an object lodges itself or becomes jammed into the System and blocks the track, it is mandatory to stop the engine and the vehicle and apply the security brake before removing object said. By avoiding to do so, the user exposes himself to sudden movement of the ATV or to breakage of a part or component coming from the System, which could cause severe injuries. It is also very important to wear full length clothing and always avoid hanging or stringy accessories.

Driving an ATV equipped with such a System requires particular precautions and a knowledge of proper driving techniques of such vehicles. An evaluation by the user of the conditions and terrain (state of the ground, grade of hill, density of snow, etc.) is equally essential. An ATV equipped with a System cannot

USER NOTICE AND DISCLAIMER

compete and/or be used to perform stunts, acrobatics or other exploits, as these could result in loss of control or severe injuries.

Insufficient knowledge of an ATV during down hill riding, climbs and crossing of obstacles and turns can result in tipping or roll over, and can cause severe injuries.

Carrying a passenger, a load or attaching a tow can cause the ATV to be less stable, and affect driveability. Unless otherwise prescribed by law and by the ATV manufacturer, you must not carry a passenger, loads or tow any objects.

The installation of a System:

- Increases ground clearance.
- Changes the center of gravity.
- Increases the ATV width and weight.
- Reduces ground pressure.

These parameters will effectively change driving characteristics of an ATV equipped with the System.

Consequentially, it is highly recommended that the user adapts his driving style in function of the new characteristics mentioned above. The driver must always use caution when he crosses obstacles, circulates through narrow paths, meets vehicles coming in the opposing direction, etc.

As it was designed, the System will considerably reduce the ATV top speed and can falsify the speedometer. Generally, the System transmission wheel diameter is less than that of the tire. Therefore, the vehicle speed will be less than that actually displayed. Whether the ATV is equipped or not with the System, users must always adapt the speed to actual driving conditions. Users must never exceed speed limits or drive faster than their capacities allow. Excessive speed remains one of the main causes of severe accidents on ATVs.

Camoplast Hi Performance Tracks is proud to offer ATV conversion kits within its wide range of products. ATV Track Systems are not only reliable, but safe. However, there are risks inherent to driving an ATV equipped with the System. It is therefore very important that any driver familiarizes himself with proper driving techniques of an ATV equipped with a System, and that he adapts his driving to his level of experience and continually evaluates operating conditions and terrain to safely and efficiently make the best of these Camoplast Hi-Performance Tracks ATV track systems.


USING THE ATV WITH TRACKS

USING THE ATV WITH TRACKS

When using a vehicle equipped with track systems, it is important to respect the following safety recommendations. As driving a vehicle equipped with track systems is different from driving a vehicle with wheels, it is strongly recommended that the safety guidelines provided below are followed to prevent any accidents and serious malfunctions that could affect the occupants, the vehicle or to the track systems for occurring.

NOTE: Non-compliance with usage recommendations can lead to a warranty claim refusal.

Pre-use inspection



WARNING

Before each ride make sure that all the wheels and moving parts of the system are free and that they are not frozen or stuck on to the frame.

Steep descents



WARNING

It is not advisable to change direction during steep descents. This can lead to a serious malfunction of the ATV's steering system and track systems. During a steep descent, it is advisable to keep the handlebar in a forward direction and to begin turning when the ATV is on flat ground, thus to avoid subjecting the components of the vehicle and the system to any high stress.



Descending and being stuck in reverse



⚠ WARNING

If the rear track systems get stuck in the snow, avoid moving or towing the vehicle in reverse to ease it from its position, as this could lead to a malfunction of the systems. If possible, move it in the forward direction to free it from the snow. It is advisable to remove the snow from the top of the rear track systems and to compact it using your feet, behind the systems to dislodge the track. Shovelling remains the best alternative in this situation.



Towing a vehicle out of the snow



⚠ WARNING

If your vehicle must be towed out of the snow, never tow it in the direction in which it sank. Tow the vehicle in the direction of the trail it left as it became stuck.




USING THE ATV WITH TRACKS

Loading a vehicle into and unloading it from a truck



WARNING

When a vehicle is being loaded into or unloaded from a truck box, it is extremely important to ensure that the front tracks do not grip the locking gudgeons of the truck's tailgate as this could cause them to tear.



Driving over an obstacle



Driving over a steep ridge



⚠ WARNING


It is not advisable to attempt to drive over an obstacle, such as a tree trunk, a big rock or a steep ridge that could lodge itself between the front and the rear track systems and immobilize the vehicle. The best option remains to bypass this type of obstacle.

Driving over an obstacle of more than 12 inches



⚠ WARNING

It is not advisable to attempt to drive over an obstacle of more than 12 inches, such as a tree trunk, an stump or a big rock. If the situation appears, insert a log or a pebble to decrease the height of the obstacle and facilitate the driving over this obstacle.



Jumping



WARNING

It is strictly forbidden to jump with vehicles equipped with track systems. These systems were not designed to carry out this type of operation. An ATV equipped with the system must never be used for the following activities: races, rallies, jumps, stunts, acrobatics or any other extreme applications.

Location of the towing cable

WARNING

If your vehicle must be towed out of the snow, never secure the cable on the track systems to tow the vehicle, the towing cable must be fixed on the vehicle frame.

WARNING

The driver must remain vigilant and cautious at all times. Powder snow and mud can hide dangerous obstacles.

 **WARNING**

The driving characteristics of your ATV will change with the installation of the System. It is important to take the time to become familiar with the Systems.

 **WARNING**

It is the driver's responsibility to verify that the air intake of the vehicle is well adapted to weather conditions and is not blocked by snow accumulation.

 **WARNING**

When travelling in groups, people driving behind vehicles equipped with a track system should be warned, as the tracks can propel dangerous objects. Be especially cautious on "rocky" trails.

 **WARNING**

Adapt your driving style to surrounding conditions (weather, traffic, etc.) and to your driving abilities.

 **WARNING**

Allow for a greater braking distance and periodically apply the brakes while driving to prevent ice buildup on brake components.

 **WARNING**

Always follow the ATV manufacturer's safety rules and regulations regarding, for example passengers transportation, maximum loads, ect.

 **WARNING**

It is the driver's responsibility to follow the recommended schedules maintenance further described in this manual.

INSTALLATION, REMOVAL AND RE-INSTALLATION

WARNING

Never place body parts under the vehicle unless it is securely placed on appropriate stands. Severe injuries could occur if the vehicle collapses or moves. Do not use a lifting device as a secure stand.

Always follow good shop practices. The place where you will be working must be security, clean, bright and well ventilated. If you are to use a floor jack, never use it as a stand. Always use appropriate stands. To avoid vehicle movement during operations, place blocks behind wheels that remain in contact with the ground. These recommendations also apply when removing parts.

WARNING

Before beginning the installation, ensure you that the vehicle is immobilized and that the engine is stopped.

WARNING

To avoid any possibilities of burn, leave time at the engine and the exhaust to cool before beginning the installation of the system.


Read this manual before proceeding with the installation work. Read Installation Guidelines included with the System for installation instructions dedicated to your ATV model.

When the system is removed and when the wheels are reinstalled on vehicle, make sure that you reinstall all the components of origin (wheels, guards, etc.) such as they were in the initial condition on the vehicle.

INSTALLATION, REMOVAL AND RE-INSTALLATION

WARNING

To avoid any injury to your hands during the manipulation of the systems, we recommend you to manipulate the systems at places indicated in following figure.



Installation

Execute all tasks described in Installation Guidelines of the vehicle model. Then, proceed to adjust the angle of attack, alignment and track tension as described in this manual. Test drive the ATV and the adjustments must be verified second time after the first use, re-adjust as required.

Removal

CAUTION: Leaving anchor brackets attached to suspension arms or anti-rotation bars attached to the skid plate when the ATV rides on wheels he can result from it grave damages in the vehicle. Never leave components other than the skid plate and foot rest reinforcement parts.

Using a lifting device, raise the ATV and install appropriate stands. Ensure that the vehicle is immobilized and safe to work on.

INSTALLATION, REMOVAL AND RE-INSTALLATION

At the front:

Remove the anti-rotation bracket cover but keep the anchor bracket attached to the anti-rotation device on the track system.

NOTE: Leave anchor bracket attached to the stabilizing rod.




Figure 1

- Remove track systems.
- Re-install wheels.

At the rear on an independent suspension:

- Same procedure as the front.

At the rear on a rigid axle suspension:

- Disconnect the anti-rotation bar from the skid plate under the vehicle.

NOTE: Leave the skid plate in place.

- Remove track systems.
- Re-install wheels.

INSTALLATION, REMOVAL AND RE-INSTALLATION

Re-installation

Always clean wheel hubs on the ATV before installing wheels or track systems.




Figure 2

NOTE: Clean wheel hubs.

- Re-install track systems at the rear and secure stabilizing rod to anchor bracket for rigid axle.
- Re-install track systems at the front.
- Tighten the fasteners in an alternate crosswise pattern to the torque recommended by the manufacturer.
- Verify track tension. Adjust if required.
- Verify angle of attack. Adjust if required.
- Verify alignment. Adjust if required.

ADJUSTMENTS

IMPORTANT

Verifying your adjustments on the system is mandatory after the first use of the vehicle, the track tension, alignment and angle of attack of the each track systems must be re-verified. Bad adjustments can decrease the performance of the system and create premature wear of certains components

NOTE: To make the following adjustments, position the vehicle on a flat and level surface

Angle of attack for front tracks systems

To obtain the correct angle of attack on front tracks systems, perform the following :

- Loosen the nut (1) compressing the spring of the stabilizing rod (refer to Figure 3).



Figure 3

ADJUSTMENTS

- Set steering handles straight ahead.
- Temporarily apply pressure to the front of the track to make sure that it stays flat on the ground.
- Install a flat bar on rear wheels of the track systems and measure the height as shown on Figure 4.




Figure 4

- Set the nut (2) shown on Figure 5 until the flat bar reaches 254 ± 6 mm above the ground. For right hand side, rotating the wrench towards A makes the system rotate towards C while rotating the wrench towards B makes the system rotate towards D (reverse for left hand side).



Figure 5

- Turn the nut (1) until it comes in contact with the spring, then compress the spring by turning this nut 1.5 turns (refer to Figure 6).




Figure 6

ADJUSTMENTS

NOTE: In certain rare cases, where the adjustment of the nut (article 1 on Figure 6) compressing the spring, is close to the end of the threaded rod, lengthen the assembly by loosening the locknut (see Figure 7) and unscrewing the rod end so that a maximum 19 mm of its threads are visible. Make sure that the locknut is well tightened after the installation.




Figure 7

Basic Tuning (front track systems):

- An adjustment of more than 254 mm measured with the flat bar, gives easier steering with wobbling effect at high speed.
- An adjustment of less than 254 mm measured with the flat bar, gives harder steering and more stability at high speed.
- More spring preload (compression) : not recommended.
- Less spring preload (compression): gives better articulation when riding on deep and powder snow. It will not affect the steering effort.

NOTE: Once the adjustment of the angle of attack on the front systems are completed, verify once again the adjustment to confirm.

Angle of attack for rear track systems

To obtain the correct angle of attack on rear tracks systems, perform the following :

Vehicles with rigid axle or trailing arm suspension

- Loosen the nut (1) compressing the spring of the stabilizing rod (see Figure 8).
- Set the nut (2) to obtain a distance of 10 mm as shown.
- Turn the nut (1) until it comes in contact with the spring, then compress the spring by turning this nut 1.5 turns.




Figure 8

NOTE: Once the adjustment of the angle of attack on the rear systems are completed, verify once again the adjustment to confirm.

ADJUSTMENTS

Vehicles with independent suspension

- Loose the bolts (1) and (2) of the bracket anti-rotation (3) to allow at the anti-rotation retainer (4) to rotate on its axis. (See Figure 9).




Figure 9

- Attach the stabilizing rod (1) to anti-rotation bracket installed on the suspension a-arm. (See Figure 10).
- Loosen the nut (2) compressing the spring of the stabilizing rod. The nut does not apply pressure on the spring (refer to Figure 10).



Figure 10

- Loosen the nut (3) compressing the rubber cone of the stabilizing rod. The nut does not apply pressure on the rubber cone (refer to Figure 10).




Figure 11

- Position the anti-rotation retainer at 90° (perpendicular) with the stabilizing rod. Tightened the two fixation bolts (1 and 2) of the bracket anti-rotation with a torque of 50 N-m. (See Figure 12).




Figure 12

ADJUSTMENTS

- Turn the nut (3) until the rubber cone are in contact with the housing of the anti-rotation retainer. The nut does not apply pressure on rubber cone (See Figure 13).




Figure 13

- Turn the nut (2) until it comes in contact with the spring. Then compress the spring by turning the nut two complete turns.




Figure 14

NOTE: Once the adjustment of the angle of attack on the rear systems are completed, verify once again to confirm the adjustment.

NOTE: In some rare cases where the adjustment of the nut (1) compressing the spring is near the end of the threaded rod, extend the rod by unlocking the jam nut (item 3 on Figure 15) and unscrew the rod to obtain 19 mm max. of visible threads. Re-tighten the jam nut.




Figure 15

Basic tuning (rear track systems):

- More gap at the rubber bushing gives better obstacle climb and flotation capacity on powder snow while moving **forward**.
- Compressing the rubber bushing gives better obstacle climb and flotation capacity while moving in **reverse** in deep and powder snow application.
- More spring preload (compression) gives better obstacle climb and flotation capacity while moving **forward**.
- Less spring preload (compression) gives better obstacle climb and flotation capacity while moving in **reverse**.

ADJUSTMENTS

Alignment

The parallelism must be adjusted with the ATV on the ground, driving forward on about 3 m and measuring toe in distance.(Refer to Figure 16).

NOTE: Every time the measurement has to be verified, drive in reverse, then, drive forward again on about 3 m.

NOTE: Verify the condition of the components of the steering system before adjusting the parallelism. Components damaged can prevent a proper adjustment and impair a good operation of the system




Figure 16

To perform adjustments on the ATV, first unlock the nut (1) of each tie rod end on the ATV. Then screw or unscrew the rod link (2) equally on both sides of the vehicle.




Figure 17

Rubber track tension

Adjust the tension the rubber track by turning the adjusting nuts of the track tensioner. Adjust track tension.




Figure 18

NOTE: The tool 1, used on the Figure 19, can be bought through an authorized Camoplast dealer. The brand is Gates Corporation and the part number is 7401-0076.

ADJUSTMENTS

The following table indicates the force (1) applied and the deflection (2) which must occur according to the conditions of use.

Season	Track	Force	Deflection
Summer	Front	15 kg	19 mm
	Rear	15 kg	19 mm
Winter (snow)	Front	11 kg	19 mm
	Rear	11 kg	19 mm



Figure 19

Basic tuning

- A higher rubber track tension reduces the risk of “detracking” and reduces drive “ratcheting” (for severe use only).
- A lower rubber track tension provides better performance, better rolling and better fuel economy (recreational use).

Final check

Ride at slow speed on a distance of about 1.5 km. Evaluate track system performance and re-adjust as required.

INSTALLATION OF A RUBBER TRACK

If possible, position the vehicle on a flat and level surface (or on a suitable lift device). Turn off the engine.

Proceed as follows :

- Set rubber track tension to the minimum (refer to Figure 20).




Figure 20

- Remove the two 201-mm wheels opposite to the track tensioner side (refer to Figure 21).
- If working on rear track systems, remove the two 133-mm wheels next to the 201-mm wheel.

INSTALLATION OF A RUBBER TRACK




Figure 21

- Install the rubber track (refer to Figure 22).

NOTE: Compare with the other rubber tracks to find the correct orientation.




Figure 22

- Re-install 201-mm wheels.

INSTALLATION OF A RUBBER TRACK

- If working on rear track systems, re-install the 133-mm wheels (refer to Figure 23).

NOTE: If possible, modify a screwdriver blade as shown on the picture to facilitate the task of inserting the wheels on their shafts. Otherwise, use a No. 2 Phillips screwdriver.




Figure 23

- Adjust track tension. Refer to 'Rubber track tension' on page 28.

BREAK-IN PERIOD

BREAK-IN PERIOD

A break-in period is necessary in order to allow the components of the system to match themselves to each others.

During the break-in period (4 hours or 80 kilometers), follow these recommendations :

- Avoid running under dry and clean conditions. (For example: asphalts, hay or straw field, etc).
- Start sharp turns at very low speed: (15 km/h maximum real speed).

BREAK IN PERIOD				
VERIFICATION	INSTALLATION	1 st hour 15 km/h max real speed	2 nd hour 25 km/h max real speed	3 rd hour 35 km/h max real speed
Track tension	X	X		
Alignment	X	X	X	X
Angle of attack	X	X		
Bolts torque				X
Visual inspection	X	X	X	X

A **GOOD** break-in period must be done in a lubricated environment such as water, mud, snow, soft soil, sand, dust, etc.

A **BAD** break-in period can generate smoke, odors of burned rubber as well as plastic deposits on the sprocket and/or the frame.

REPLACEMENT OF A WHEEL WITH EXTRACTOR

WARNING

Do not use air tools to remove the wheels.

Use Camoplast extractor # 2000-00-1050 (article 1, Figure 24), and the following procedure to make the replacement:




Figure 24

- Remove the rubber cap of the wheel. If the wheel is retaining by a bolt, unscrew it and remove the wheel.
- If there is no bolt, use the alignment sleeve (article 2, Figure 24) to locate the extractor.

REPLACEMENT OF A WHEEL WITH EXTRACTOR

- Place the extractor under the wheel as shown on Figure 25
- Then screw the threaded rod to remove the wheel




Figure 25

- Insert the new wheel on the shaft until it reaches the shoulder.

MAINTENANCE SCHEDULE

WARNING

Do not insert hands or feet into or near the System unless the engine is off, and the vehicle is stopped with the security brake engaged.

For optimum performance and maximum durability, please refer to the following maintenance grid :

MAINTENANCE PROGRAM		
Element to check and maintain	Frequency	
	After break-in	
	Winter condition	Abrasive 4 seasons condition
General: Bolts torque	20 hours	20 hours
General: Vehicle alignment	10 hours	10 hours
General: Visual inspection	Before riding	Before riding
Track: Tension	20 hours	20 hours
Track: Wear	Once per year	Once per year
Wheels: Lateral wear	Once per year	40 hours
Wheels: Bearings	Once per year	20 hours
Frame: Track guide wear	Once per year	20 hours
Frame: Main hub bearing	Once per year	50 hours
Frame: Stabilizer (tandem)	Once per year	50 hours
Frame: Cracks & Inspection	Once per year	Once per year
Anti-rotation: Adjustment / Bolt torque	20 hours	20 hours
Anti-rotation: Cracks and deformation	Before riding	Before riding
Sprocket: Wear	Once per year	50 hours

NOTE: Do not use a brake cleaning solvent to clean the track system. This may damage sealing components and stickers.

WARNING

After extreme environment uses (mud and water) and inspecting all bearings once a year, please note that bearings cannot be re-greased like snowmobile bearings. If they need to be serviced replace the wheel completely. Some of the components (i.e. 133 mm wheels) need special tool for servicing. Please use appropriate tools to avoid any damage to your component.

TORQUE TABLE

TORQUE TABLE

Bolt	N-m (lb/ft)
M8 - 8.8	25 (18)
M10 - 8.8	50 (36)
M10 - 10.9	70 (50)
M12 - 10.9	125 (92)

NOTE: Use a threadlocker Loctite 263 type or its equivalent at the indicated places in the explode view of the system in this manual.

⚠ WARNING

Overtightening the bolts of some parts may damage them and security features may be affected.

STORAGE

The best way to store the System is to lay down each frame on its side, away from direct sunlight.




Figure 26

WEAR

Wheel

Verify the wear of the wheels especially on the interior guidance strip (Figure 27). If the internal plastic structure is visible, the rubber coating is worn and the wheel must be replaced (as illustrated Figure 28-2), or when the wear of the wheel's rolling band reaches a thickness of 17 mm, Figure 29 (20.5 mm when new). A wheel that is excessively worn will not offer enough support for the track's guidance.




Figure 27

WEAR




Figure 28




Figure 29

Track guide

Verify the wear of the track guide by measuring the width of the guide. If dimensions of the guide illustrated in Figure 30 are lower than 5 mm, at any place, replace the part. If the guidance strip is worn so that the concave shape is no longer visible, replace the part. An overly worn track guide could prematurely wear the other components of guidance of the system.




Figure 30

Track

Verify the wear of the track by inspecting the rolling path, the driving lug, the profile and the internal and external condition of the track's carcass. Make sure that the track's internal structure are not visible at cuts or worn area. Too much wear could cause damage to the wheels and to the track's guide.

WEAR

Sprocket

Check the wear of the sprocket by measuring the part as illustrated on Figure 31. Replace the part when dimensions are lower than 19 mm. An excessive wear could lower the efficiency of the drive of the track and reduce the system's performance.




Figure 31

Anti-rotation

Verify the wear of anti-rotation system, mainly at the ball joint (Figure 32) to make sure that it is not seized or extremely loose. Ball joint damage could harm the performance of the track system




Figure 32

WARRANTY

Camoplast Hi-Performance Tracks guarantees that the new, unused **Camoplast T4S** System (System) installed by an authorized dealer or distributor is free from any defects in materials and workmanship during the period and in conditions described below. When operating a new **Camoplast T4S** System, the user agrees that the present form is applicable and exclusive, that they have been signified and that they have been accepted by him/her at the time of purchase.

The ATV **Camoplast T4S** track system is covered by a manufacturer warranty (warranty). The warranty covers manufacturing defects related with materials and workmanship. The installation and maintenance of the System is always the responsibility of the owner.

PERIOD OF COVERAGE

The warranty is valid for a period of twelve (12) months following the date of purchase. This warranty does not apply to normal maintenance.

The warranty applies exclusively to parts and components of the track system. All paint defects on the System (frames and components) are not covered.

The warranty is not valid if the System is not installed by an authorized Camoplast Hi-Performance Tracks network dealer or distributor.

This warranty specifically excludes any damage or breakage to the ATV and related defects on the ATV, whether or not these were caused or believed to be caused by the System.

The manufacturer is not responsible for damages, injuries or loss caused at the time of or after installing of the System on the vehicle.

For a warranty to be valid, the System owner must comply with manufacturer notices and warnings. In addition, all claims must be accompanied by a proof of purchase (original receipt or sale contract) and work or repairs must be performed by an authorized Camoplast Hi-Performance Tracks dealer. All claims not previously approved and authorized by Camoplast Hi-Performance Tracks will be rejected.

The following situations and items are not under any circumstances covered by the warranty :

- 1) Any and all consequential damages, including, but not limited to, indirect costs, such as towing, storage, phone calls, renting, transportation, inconveniences, insurance coverage, reimbursement of loss, loss of time and loss of revenue, etc.
- 2) Damage resulting from faulty installation.
- 3) Damage resulting from normal parts wear or progressive deterioration owing to the distance covered with a vehicle on which the System is installed.

- 4) Damage resulting in non-compliance with the user manual and with maintenance instructions recommended in the user's manual and other technical documents.
- 5) Damage resulting in abusive use, abnormal use, negligence or even a use which does not comply with recommendations of the manual, excess weight or loading, including excessive number of passengers.
- 6) Labour costs, parts and materials related any and all maintenance costs.
- 7) Damage resulting from faulty repairs, improper maintenance or any unauthorized changes made to the System other than those specified by the manufacturer or from the installation of non-original or unauthorized parts that were not produced or approved by Camoplast Hi-Performance Tracks.
- 8) Damage resulting from an accident, incident, robbery, vandalism, war or unforeseen event or act of God.
- 9) Regardless of cause, damage resulting from inexperience, driving errors, accident or other incident.
- 10) The use of the System on a vehicle used for public rental, including by a previous owner, will render this warranty null and void.
- 11) The use of the System in races, rallies or other competitive events/activities of this type, at any time, including from a previous owner or in conditions that do not comply with those described by the manufacturer will render the warranty null and void.

Any repaired or replaced components or parts are guaranteed only to the extent of the original warranty. in other words: if a warranted part was replaced after five (5) months, the new replacement part will only be guaranteed for seven (7) months, for a total of twelve (12) months. In no event shall the warranty extend beyond a total of twelve (12) months from the date of original System purchase.

In all cases, the warranty is limited to a maximum of the original purchase price or the fair market value of the System. Camoplast Hi-Performance Tracks will have final authority in determining the fair market value of a used System. The warranty is applicable within the limits and conditions initially provided for in if the System is determined to be unusable due to accident or improper repair, the warranty will be considered null and void without further recourse available to the System owner.

The manufacturer, the retailer and / or the repair shop shall not be held responsible for any delays caused by material, parts or components availability or backorder.

*Shipping and handling costs, as well as any fees related with shipping or transportation of the System to the dealer location are the responsibility of the System owner.

Camoplast Hi-Performance Tracks reserves its sole and exclusive right to update or modify this warranty without impact on end users. All previous terms and conditions of the warranty at time of purchase will be respected.

TROUBLESHOOTING

TROUBLESHOOTING

TROUBLE SHOOTING		
Problem	Potential cause	Correction to do
Abnormal vibration	Presence of debris in the system.	Remove any debris which could prevent the proper operation of the system
	Severe and localized wear of a wheel (flat spot)	Replace the part
	Sprocket or wheel frozen	Remove the ice/snow build up. Storing the vehicle at temperature superior to 0 °C to might be required
	Beginning of detracking	Make sure that the track is well guided by the wheels and the track guide. Realign the system if it's needed.
	The presence of dirt on the ATV during the installation of the system could cause a bad seating of mating surfaces of the hubs of the ATV and the track system.	Remove the system and clean the contact surfaces between the hubs.
	Hub or wheel bearing damaged	Replace the damaged bearing
Unstable behavior	Hub of the ATV or of the track system deformed following an impact or an abusive use	Replace the deformed part
	Bad ajustement of the attack angle of the track system.	Adjust the attack angle according to the specifications of the manufacturer. (Refer to the "ajustment" section of the manual)
Overheat of the guidance components of the system (burned rubber odor)	Track tension too high	Adjust of the track tension. (Refer to the "ajustment" section of the manual)
	Wrong alignment of the system	Correct the system alignment (Refer to the "ajustment" section of the manual)
	Wheel blocked	Try to free the wheel and replace if necessary
	Constant turn	Vary your turning radius and seek for areas which can lubricate the system
Loss of power	Uninterrupted Use of the system in paths with ruts	Vary your line (out of he ruts) and seek zones which can lubricate the system
	Track tension too high	Clean the sprocket of mud, snows or any contaminants build up. Remove ice/snow build up on wheels Clear frame and wheels of compacted snow.
Partial or total detracking	Infiltration of snow in the air intake system of the ATV.	Remove snow and immediately contact the dealer to fix the situation.
	Severe wear of one or several components	Verify track guide and wheels wear.
	Track tension too low	Adjust the track tension. (Refer to the "ajustment" section of the manual)
Insufficient snow flotation	Wrong alignment of the track system and/or of the attack angle.	Adjust the attack angle and alignment according to the specifications of the manufacturer. (Refer to the "ajustment" section of the manual)
	Wrong ajustement of the anti-rotation	Adjust the attack angle according to the specifications of the manufacturer. (Refer to the "ajustment" section of the manual)

SERIAL NUMBER LOCATION

The following pictures show the location of the serial numbers on the track system frame and rubber track.




Figure 33



Figure 34

TECHNICAL SUPPORT

If your dealer or distributor is unable to solve a problem related with the System, you may contact the Camoplast Hi-Performance Tracks support team from Monday to Friday.

Camoplast Solideal Inc.

4162, Burrill - Local A
Shawinigan, (Québec) G9N 0C3 CANADA

E-mail : atvtracksystems@camoplastsolideal.com

Website : www.camoplastsolideal.com

"CE" DECLARATION OF CONFORMITY



"CE" DECLARATION OF CONFORMITY

WE:

MANUFACTURER : **CAMOPLAST SOLIDEAL INC.**

ADDRESS : 4162, Burrill, Local A
Shawinigan (Québec) Canada
G9N 0C3

PHONE :
FAX :
WEB SITE : www.camoplastsolideal.com

HEREBY SOLE RESPONSABILITY THE CONFORMITY OF THE PRODUCT SERIES

PRODUCT : ATV Tracks Systems
COSTUMER :

WITH THE FOLLOWING STANDARDS

NUMBER :	TITLE:	DATE :
-EN 62079	Preparation of Instruction	2001
-EN 12100-1 & -2	Safety of Machinery	1996
-EN 17050-1 & -2	Conformity Assessment	2005

AND IN CONFORMITY WITH THOSE EC DIRECTIVES:

NUMBER :	TITLE:	DATE :
2006/42/EEC	Safety of machinery directives	2006


DONE AT: Shawinigan (Québec) Canada

RESPONSABLE NAME: _____

TITLE : _____


DATE : _____ SIGNATURE : _____

This page is left intentionally blank.



ITEM #	PART #	DESCRIPTION	QTY
		TATOU ATV T4S MY2012 FRONT LEFT & RIGHT	
1	1009-00-7115	INJ SPROCKET, 15 TEETH / BARBOTIN INJ, 15 DENTS	1
2	1009-00-7116	INJ SPROCKET, 16 TEETH / BARBOTIN INJ, 16 DENTS	1
3	1009-00-7117	INJ SPROCKET, 17 TEETH / BARBOTIN INJ, 17 DENTS	1
4	1009-00-7118	INJ SPROCKET, 18 TEETH / BARBOTIN INJ, 18 DENTS	1
5-A	1010-00-7222	RH FRONT FRAME / CADRE AVANT DROIT - TATOU ATV T4S	1
5-B	1011-00-7222	LH FRONT FRAME / CADRE ARRIERE GAUCHE - TATOU ATV T4S	1
6	1001-00-7102	STABILIZING ROD ASS'Y / BRAS STABILISATEUR ASSEMBLÉ, 200 LBS/IN	1
7	1014-00-7222	TENSIONNER / TENSIONNEUR DE CHENILLE - TATOU ATV 4S	1
8	1015-00-7010	STABILIZER ASS'Y / TANDEM ASSEMBLÉ	1
9	1015-00-7103	STABILIZER W/ WHEELS ASS'Y / TANDEM AVEC ROULETTE, ASSEMBLÉ	1
10	1016-00-0201	201mm INJECTION ATV WHEEL ASS'Y / ROULETTE INJECTÉ ATV 201 MM	4
11	1016-00-0133	133mm INJECTION ATV WHEEL ASS'Y / ROULETTE INJECTÉ ATV 133 MM	7
12	1017-00-0001	2 LIPS CAP, 1-3/4" O.D. TUBE / BOUCHON DOUBLE REBORD, TUBE 1-3/4" O.D.	1
13	1017-00-0005	2 LIPS CAP, 1" O.D. TUBE / BOUCHON DOUBLE REBORD, 1" O.D. TUBE	6
14	1017-00-0010	2 LIPS CAP, 2" O.D. TUBE (LDPE) / BOUCHON DOUBLE REBORD, TUBE 2" O.D.	1
15	1017-00-0110	2 LIPS CAP, 2" O.D. TUBE (ESPRENE) / BOUCHON DOUBLE REBORD, TUBE 2" O.D.	11
16	1017-00-7081	HUB CAP BLUE (HOT STAMPED) ASS'Y / CAP DE MOYEU BLEU ASSEMBLÉ	1
17	1019-05-0010	POLARIS HUB, ASS'Y / ESSIEU POLARIS, ASSEMBLÉ	1
18	1019-77-0031	MULTI-MODEL HUB (METRIC) ASS'Y / ESSIEU MULTI-MODELES, ASSEMBLÉ	1
19	1033-08-0080	HEX SCR / VIS HEX - ISO 4014, 8.8, ZP / M8x1.25x80	1
20	1033-10-2026	HEX SCR W/WASH / VIS HEX A/ ROND - 30x3, 8.8, ZP, TL 9S-1026 / M10x1.5x25	5
21	1036-10-4030	SERRATED HEX SCR / BOUL HEX DENTELÉ - DIN 6921, 10.9, ZP, TL 9S-1026 / M10x1.5x30	4
22	1036-12-4030	HEX FLG SCR/BOUL HEX À EMBASE - DIN 6921, 10.9, ZP, TL 9S-1026 / M12x1.75x30	1
23	1049-00-0007	WAFER SQ DR DRILL SCR / VIS AUTOTARAUDEUSE - ZP, #12-24 x 1.5"	4
24	1050-00-0016	SLIDE BUSHING / COUSSINET POUR LISSE	1
25	1050-00-0011	BUSHING / COUSSINET - 5/8" O.D. x 27/32" I.D. x 18" LG	4
26	1051-00-0015	TENSIONNER BUSHING / COUSSINET TENSIONNEUR	1
27	1051-00-0037	INTERNAL SPACER / ESPACEUR INTERNE	1
28	1061-00-0025	WASHER SPINDLE HUB / RONDELLE AXE MOYEU - ID. 0.52 X OD. 1.63 X 0.109 THK.	1
29	1074-08-0001	HEX FL NY NUT / ÉCROU HEX NYLON EMBASE - ISO 4161, 8.8, ZP / M8x1.25	1
30	1082-00-7001	WHEEL AXLE, STABILIZER / AXE DE ROUES, STABILISATEUR	1
31	1082-00-7110	WHEEL AXLE COMPLETE KIT / AXE DE ROUE ENSEMBLE COMPLET	1
32	1082-00-7050	TENSIONNER ROD ASS'Y / TIGES DE TENSIONNEUR ASSEMBLÉ	1
33	1083-00-8002	STICKER - WARNING / AUTOCOLLANT - AVERTISSEMENT	1
34	-	STICKER - SERIAL NUMBER / AUTOCOLLANT - NO SÉRIE - TATOU ATV T4S	1
35-A	1083-00-8100	STICKER - FRONT LEFT PICTOGRAM / AUTOCOLLANT - PICTOGRAMME AVANT GAUCHE	1
35-B	1083-00-8110	STICKER - FRONT RIGHT PICTOGRAM / AUTOCOLLANT - PICTOGRAMME AVANT DROIT	1
36	1083-00-7375	STICKER / AUTOCOLLANT - TATOU ATV T4S MY2012	1
37	1085-00-7010	TRACK GUIDE / GUIDE DE CHENILLE - TATOU T4S	1
38	1090-00-0001	BALL BEARING, SEALED / ROULEMENT À BILLES, HERMÉTIQUE - 6007 DU2	2
39	1093-00-7000	RUBBER CONE, STABILIZER / CONE DE CAOUTCHOUC, STABILISATEUR	2
40	1093-00-7002	SHAFT SEAL / JOINT D'ÉTANCHÉITÉ POUR ARBRE - 50 x 62 x 10 TC	1
41	1093-00-7600	TRACK / CHENILLE - 11.5" x 93.38" x 1.00" (9150S)	1
42	1093-00-7009	WHEEL SEAL / JOINT D'ÉTANCHÉITÉ POUR ROULETTE - (25 ID X 42 OD)	11
A	1000-00-7002	THREADED ROD, STABILIZING ROD / TIGE FILETÉE, BRAS STABILISATEUR	1
B	1033-10-1060	HEX SCR / VIS HEX - ISO 4014, 10.9 ZP / M10x1.5x60	1
C	1050-00-0013	ROD END SPACER / ESPACEUR TIGE À CÊL	2
D	1047-00-7010	ROD END, STABILIZING ROD / TIGE À CÊL, BRAS STABILISATEUR	1
E	1060-00-0004	WASHER / RONDELLE - 8, ZP, 7/16IDx10Dx0.072T	1
F	1071-20-0001	HEX NYLON NUT / HEX NYLON NUT - ISO 7040 8.8, ZP / M20x2.5	2
G	1073-12-3002	HEX THIN NUT / ÉCROU MINCE HEX - 8.8, ISO 4037, ZP / M12x1.25	1
H	1074-10-0001	HEX FL NY NUT / ÉCROU HEX NYLON EMBASE - ISO 4161, 8.8, ZP / M10x1.5	1
I	1080-00-0002	COMPRESSION SPRING / RESSORT DE COMPRESSION - 200 LBS/IN	1
J	1093-00-7007	RUBBER DAMPER / AMORTISSEUR EN CAOUTCHOUC	1
K	1033-AS-0025	STABILIZING ROD SHORT BOLTS KIT / ENSEMBLE BOULON COURT BRAS STABILISATEUR	1


2011-10-31 / rev B



RV00164-00_A


ITEM #	PART #	DESCRIPTION	QTY
		TATOU ATV T4S MY2012 REAR LEFT & RIGHT	
1	1009-00-7115	INJ SPROCKET, 15 TEETH / BARBOTIN INJ, 15 DENTS	1
2	1009-00-7116	INJ SPROCKET, 16 TEETH / BARBOTIN INJ, 16 DENTS	1
3	1009-00-7117	INJ SPROCKET, 17 TEETH / BARBOTIN INJ, 17 DENTS	1
4	1009-00-7118	INJ SPROCKET, 18 TEETH / BARBOTIN INJ, 18 DENTS	1
5-A	1012-00-7222	RH REAR FRAME / CADRE ARRIÈRE DROIT - TATOU ATV T4S	1
5-B	1013-00-7222	LH REAR FRAME / CADRE ARRIÈRE GAUCHE - TATOU ATV T4S	1
6	1014-00-7322	TENSIONNER / TENSIONNEUR DE CHENILLE - TATOU ATV 4S	1
7	1016-00-0201	201mm INJECTION ATV WHEEL ASS'Y / ROULETTE INJECTÉ ATV 201 MM	4
8	1016-00-0133	133mm INJECTION ATV WHEEL ASS'Y / ROULETTE INJECTÉ ATV 133 MM	8
9	1017-00-0001	2 LIPS CAP, 1-3/4" O.D. TUBE / BOUCHON DOUBLE REBORD, TUBE 1-3/4" O.D.	1
10	1017-00-0010	2 LIPS CAP, 2" O.D. TUBE (LDPE) / BOUCHON DOUBLE REBORD, TUBE 2" O.D.	1
11	1017-00-0110	2 LIPS CAP, 2" O.D. TUBE (ESPRENE) / BOUCHON DOUBLE REBORD, TUBE 2" O.D.	12
12	1017-00-7081	HUB CAP BLUE (HOT STAMPED) ASS'Y / CAP DE MOYEU BLEU ASSEMBLÉ	1
13	1019-05-0010	POLARIS HUB, ASS'Y / ESSIEU POLARIS, ASSEMBLÉ	1
14	1019-77-0031	MULTI-MODEL HUB (METRIC) ASS'Y / ESSIEU MULTI-MODÈLES, ASSEMBLÉ	1
15	1033-08-0080	HEX SCR / VIS HEX - ISO 4014, 8.8, ZP / M8x1.25x80	1
16	1033-10-2026	HEX SCR W/WASH / VIS HEX A/ ROND - 30x3, 8.8, ZP, TL 9S-1026 / M10x1.5x25	6
17	1036-10-4030	SERRATED HEX SCR / / BOUL HEX DENTELÉ - DIN 6921, 10.9, ZP, TL 9S-1026 / M10x1.5x30	4
18	1036-12-4030	HEX FLG SCR / BOUL HEX À EMBASE - DIN 6921, 10.9, ZP, TL 9S-1026 / M12x1.75x30	1
19	1049-00-0007	WAFER SQ DR DRILL SCR / VIS AUTOTARAUDEUSE - ZP, #12-24 x 1.5"	4
20	1050-00-0016	SLIDE BUSHING / COUSSINET POUR LISSE	1
21	1050-00-0011	BUSHING / COUSSINET - 5/8" O.D. x 27/32" I.D. x 18" LG	4
22	1051-00-0015	TENSIONNER BUSHING / COUSSINET TENSIONNEUR	1
23	1051-00-0037	INTERNAL SPACER / ESPACEUR INTERNE	1
24	1061-00-0025	WASHER SPINDLE HUB / RONDELLE AXE MOYEU - ID. 0.52 X OD. 1.63 X 0.109 THK.	1
25	1074-08-0001	HEX FL NY NUT / ÉCROU HEX NYLON EMBASE - ISO 4161, 8.8, ZP / M8x1.25	1
26	1082-00-7001	WHEEL AXLE, STABILIZER / AXE DE ROUES, STABILISATEUR	2
27	1082-00-7012	AXLE, REAR STABILIZER / ESSIEU, STABILISATEUR ARRIÈRE	1
28	1082-00-7110	WHEEL AXLE COMPLET KIT / AXE DE ROUE ENSEMBLE COMPLET	1
29	1082-00-7050	TENSIONNER ROD ASS'Y / TIGES DE TENSIONNEUR ASSEMBLÉ	1
30	1083-00-8002	STICKER - WARNING / AUTOCOLLANT - AVERTISSEMENT	1
31	-	STICKER - SERIAL NUMBER / AUTOCOLLANT - NO SÉRIE - TATOU ATV T4S	1
32-A	1083-00-8120	STICKER - REAR LEFT PICTOGRAM / PICTOGRAMME ARRIÈRE GAUCHE	1
32-B	1083-00-8130	STICKER - REAR RIGHT PICTOGRAM / PICTOGRAMME ARRIÈRE DROIT	1
33	1083-00-7375	STICKER / AUTOCOLLANT - TATOU ATV T4S MY2012	1
34	1085-00-7010	TRACK GUIDE / GUIDE DE CHENILLE - TATOU T4S	1
35	1090-00-0001	BALL BEARING, SEALED / ROULEMENT À BILLES, HERMÉTIQUE - 6007 DU2	2
36	1093-00-7000	RUBBER CONE, STABILIZER / CÔNE DE CAOUTCHOUC, STABILISATEUR	2
37	1093-00-7002	SHAFT SEAL / JOINT D'ÉTANCHÉITÉ POUR ARBRE - 50 x 62 x 10 TC	1
38	1093-00-7006	TRACK / CHENILLE - 12.5" x 98.57" x 1.188" (9100S)	1
39	1093-00-7009	WHEEL SEAL / JOINT D'ÉTANCHÉITÉ POUR ROULETTE - (25 ID X 42 OD)	12

2011-10-31 / rev B



RV00162-00_A

ITEM #	PART #	DESCRIPTION	QTY
		TATOU ATV T4S MY2012 INDEPENDENT SUSPENSION (IS)	
1	1000-00-7002	THREADED ROD, STABILIZING ROD / TIGE FILETÉE, BRAS STABILISATEUR	1
2	1001-00-7102	STABILIZING ROD ASS'Y / BRAS STABILISATEUR ASSEMBLÉ - 200 LBS/IN	1
3	1015-00-8250	UNIVERSAL BRACKET ANTI-ROT. ASSY. (IS) / ANCRAGE UNIVERSEL ANTI-ROT. ASS. (SI)	1
4	1015-00-7026	BACK PLATE / PLAQUE DE FIXATION ARRIERE	1
5	1033-10-1060	HEX SCR / VIS HEX - ISO 4014, 10.9 ZP / M10x1.5x60	1
6	1033-10-2026	HEX SCR W/WASH / VIS HEX A/ ROND - 30x3, 8.8, YZN, TL 9S-1026 / M10x1.5x25	2
7	1047-00-7010	ROD END, STABILIZING ROD / TIGE À CÊIL, BRAS STABILISATEUR	1
8	1050-00-0013	ROD END SPACER / ESPACEUR POUR TIGE À CÊIL	2
9	1060-00-0004	WASHER / RONDELLE - 8, ZP, 7/16IDx1ODx0.072T	3
10	1071-20-0001	HEX NYLON NUT, ISO 7040 8.8, ZP / M20x2.5	2
11	1073-12-3002	HEX THIN NUT / ÉCROU MINCE HEX - 8.8, ISO 4037, ZP / M12x1.25	1
12	1074-10-0001	HEX FL NY NUT / ÉCROU HEX NYLON EMBASE - ISO 4161, 8.8, ZP / M10x1.5	3
13	1080-00-0002	COMPRESSION SPRING / RESSORT DE COMPRESSION - 200 LBS/IN	1
14	1093-00-7007	RUBBER DAMPER / AMORTISSEUR EN CAOUTCHOUC	1
15	1033-AS-0025	STABILIZING ROD SHORT BOLTS KIT / ENSEMBLE BOULON COURT BRAS STABILISATEUR	1
		2011-10-31 / rev B	



ITEM #	PART #	DESCRIPTION	QTY
		TATOU ATV T4S MY2012 RIGID SUSPENSION (RS)	
1-A	1015-00-7004	LH, BRACKET ANTI-ROTATION (RS) / ANCRAGE ANTI-ROTATION, GAUCHE (ER)	1
1-B	1015-00-7014	RH, BRACKET ANTI-ROTATION (RS) / ANCRAGE ANTI-ROTATION, DROIT (ER)	1
2	1015-05-7005	SPACER / ESPACEUR - 5/8"	VAR
3	1015-00-7026	BACK PLATE / PLAQUE DE FIXATION ARRIÈRE	1
4	1033-10-2026	HEX SCR W/WASH / VIS HEX A/ ROND - 30x3, 8.8, YZN, TL 9S-1026 / M10x1.5x25	2
5	1033-10-2045	HEX SCR W/WASH / VIS HEX A/ ROND - 25x2,8.8, YZN, TL 9S-1026 /	VAR
6	1050-00-0011	BUSHING / COUSSINET - 5/8" O.D. x 27/32" I.D. x 18" LG	1
7	1060-38-0114	WASHER / RONDELLE - 8, ZP, 13/32IDx1-1/4ODx0.120T	1
8	VAR	REFER INSTALLATION GUIDE LINES DOCUMENTATION / RÉFÉRER DOCUMENTATION DU GUIDE D'INSTALLATION	1
		2011-10-31 / rev B	